



IMPORTANT:
VOICE CONTROL FUNCTION ONLY AVAILABLE ON TVs THAT SUPPORT THIS FUNCTION!

Please Note: only 1 remote can be registered to the TV at one time.





You must use brand new alkaline batteries only. Do not mix new batteries with old batteries.

- Failure to match the correct polarities of the battery may cause the battery to leak.

Pairing (connecting) the Samsung Smart Remote to your TV

1. With the TV powered ON, point the remote towards the TV then press and hold the  and  buttons simultaneously for 3 seconds or more.
2. When the Bluetooth Icon is displayed on your TV screen, release the two buttons on your Smart Control remote.
3. Your TV will begin pairing with your Smart Control remote.
4. When paired properly, the Pairing Complete Check Mark will appear indicating that your remote is now paired to your TV.

****If your remote does not pair to your TV, you will need to reset your Smart Control remote****

To reset the Smart Control remote, press and hold the  and ( or  or  depending on model) simultaneously for 4 seconds. Now follow steps 1 through 4 above.

If the TV fails to register Remote

Remove the batteries from the remote.

Unplug the TV for 60 seconds. Plug the TV back into the wall.

Start at step 1

Important- If you cannot get the remote to work, please email us your full TV model number before returning. We can usually help! Thank you.